



# ACCESSIBLE GAMING CONTROLLER QUICK START GUIDE

The *Accessible Gaming Controller* or AGC is a collection of input devices including switches, a joystick and Microsoft Xbox Adaptive Controller along with mounting systems enabling children with a wide range of disabilities to play independently or collaboratively.

## USE AND SET- UP

Slide each leg into place and tighten each knob to secure it. The shorter two legs are closest to the user. Adjust the height of the gaming table by loosening the lower knobs on the four legs and position at the desired height, tighten the legs. Adjust the foot pedal angle by loosening the two knobs and move the plate to the desired angle, tighten the knobs.

## MONTING INPUT DEVICES

Attach the Xbox Adaptive Controller by placing the controller on the top of the gaming table and secure it in place with a thumb screw through the hole in the back. Switches mount with pins and magnets; place them in the desired location by lining up the pins with the holes and dropping in.

The adaptive controller breaks out each button used on the Xbox system. To connect a switch, plug it into the jack on the back of the adaptive controller which you would like it to control. The joystick can be plugged into the left or right side of the adaptive controller, depending on what you would like it to control.

## POWERING ON THE AGC AND CHARGING DEVICES

The monitor power button is located on the back side at the bottom. The Xbox, Accessible controller and standard controller's power buttons appear as a black circular X button.

The Accessible controller gets plugged in from the back side to charge, connect it to the Xbox with the provided USB cable. The standard controller takes two AA batteries.

For more detail on using the Xbox Adaptive Controller and input devices, please visit <https://support.xbox.com/en-US/xbox-one/controllers/adaptive-controller-info>